

1. Connect Upright to Base bushing using large Philips Head Screws provided (round base image shown, but installation is the same for all other bases).
2. Remove plastic endcap and insert clear plastic shield:
 - 2a. For shield with bottom pass-through – Insert protection shield into upright channel (short set screws may need to be loosened before inserting protection shield) using a small screwdriver, or you can use the side of a credit card. Once inserted, tighten the short set screws to hold the shield firmly in place. Repeat on the opposite upright.
 - 2b. For full height shield – Remove the long set screw (fig. 2b) from the upright using a small flathead screwdriver, or you can use the side of a credit card. Next, insert protection shield into the upright channel (short set screws may need to be loosened before inserting protection shield). Once inserted, tighten the short set screws to hold the panel firmly in place. Repeat on opposite upright.
3. Replace plastic end caps.

