



1 Unzip the nylon bag and cut the yellow banding holding the boxes together.



2 Remove two cardboard boxes and steel base section from bag.



3 Slide top and bottom sections of unit out of protective cardboard boxes.



4 Slide bottom section on to posts of base plate section.



5 Slide top section on to posts of bottom section. Assembly is complete.

